

G4-FLX SERIES PUSH NOTIFCATIONS SETUP GUIDE

Enabling Push Notifications


FX-XVR/NVR Setup

Note: Make sure to setup and enable any of the alarm features on your G4-Flux device beforehand if you wish to utilize these features within the push notification section of the G4-FLX-VMS application.


- 1. Hook up your G4-FLX device to your display monitor and login to your administrator account.
- 2. Go to the Main Menu and select "Alarm".



3. Within the "**Event Notification**" tab located in the top right corner of the page select the option labeled "**Push Message**".



4. Within the Push Message section select the box next to "**Enable**" and then select "**Apply**" to save. (Reference image via the next page)




G4-FLX-VMS Phone Application Push Settings

- 1. Open up the **G4-FLX-VMS** phone application via your Iphone or Android device.
- 2. Select the menu option located within the top left corner of the application and then select the option labeled "**Push Settings**".



3. Within the Push Setting select the device you would like to enable Push notifications for. In this setup we will be selecting the option labeled testdemo.



4. This will prompt you to a new page in which you will enable the option labeled "**Device** Notification Function".



5. Doing so will extend out multiple options allowing you to choose what type of push notifications you would like to receive. In this guide we will demonstrate enabling a motion triggered push notification. To do so simply select the option labeled "**Motion**".

<	testdemo		
Device Notifica	tion Function		$\Big)$
Message Subso	cription		$\Big)$
Trigger a Push	Message	Live	>
Intelligent Alarm			
Exception		Close all	>
Object Detectio	n	Close all	>
Intrusion Detec	tion	Close all	>
Line Crossing		Close all	>
Basic Alarm			
Motion		Close all	>
Sensor Alarm	Sensor5,S	ensor6,Se	\rangle
Camera Offline			
Diels Deed and M	Muito Export		

6. Select the camera(s) you would like to receive motion triggered push notifications for and once complete select the save icon located within the top right corner.

	<	testdemo	2	LL I
	Dev	ice Notification Function		\bigcirc
	Me	ssage Subscription		\supset
	Trig	iger a Push Message	Live	>
	Intel	Motion	\bigcirc	I
Exic Obj Intr Lin Basi	IP Camera	Ø	>	
	Obj	IPX11	\bigcirc	>
	In tr	TD-9482E2	\bigcirc	>
	Li n Basi			>

Receiving/Reviewing Push Notifications

Once all push notifications required are set and saved, you will then receive a notification whenever the alarms enabled are triggered.

(((.		₩	*	$\langle \! \diamond \! \rangle$			
 G4-FLX-VMS 2:27 PM G4-FLX-VMS Hide 							
NOTIFICATION SETTINGS CLEAR ALL							

In order to review your notification(s) you can either select the notification when triggered via your mobile phone or you can navigate to the notification section within the G4-FLX-VMS application. The notification section is found within the applications main menu.



Within the Notification section you will find all of the triggered alarms that have been set off. To review an alarm simply select the option within the list.

